


## APAVU IZMĒRU TABULA BĒRNIEM W PLATUMA APAVIEM

A	Pēdas vai ortozes garums
B	Apava zoles garums
C	Apava zoles platums
D	Apkārtmērs*
E	Apkārtmērs*



APAVU MODEĻI	IZMĒRI	20	22	23	24	25	27	28	30	31	32	33	34	36	37	38	39
		A	12.2	13.2	14.1	14.8	15.7	16.7	17.5	18.4	19.2	20.2	21.0	21.7	22.7	23.5	24.3
	B	13.3	14.3	15.2	15.9	16.8	17.8	18.4	19.4	20.3	21.3	21.9	22.9	23.8	24.4	25.4	26.4
	C	6.0	6.2	6.4	6.7	6.8	7.0	7.3	7.5	7.6	7.8	7.9	8.3	8.6	8.9	9.1	9.2
Billy CS lace high top	D	16.5	17.1	17.8	18.4	19.1	19.4	19.7	20.3	21.0	21.6	21.9	22.5	23.2	23.8	24.1	24.4
	E**	20.3	21.0	21.6	22.2	22.5	23.2	23.8	24.4	25.1	25.	26.7	27.3	27.9	28.5	29.2	29.8
Billy CS lace low tops, Hoop& court	D	15.2	15.9	16.5	16.8	17.1	18.1	18.7	19.1	19.4	20.0	20.6	21.3	21.6	22.2	22.9	23.5
	E**	18.4	19.1	19.7	20.3	20.6	21.6	22.2	23.2	23.8	24.4	25.1	25.7	26.7	27.3	27.9	28.5
Billy cozy boots	D	15.2	15.9	16.5	16.8	17.1	18.1	18.7	19.1	19.4	20.0	20.6	21.3	21.6	22.2	22.9	23.5
	E	18.1	18.4	19.1	19.7	20.3	21.0	21.6	22.2	23.2	23.8	24.4	25.1	25.7	26.7	27.3	27.9
Billy lug boots	D	16.5	17.1	17.8	18.4	19.1	19.4	19.7	20.3	21.0	21.6	21.9	22.5	23.2	23.8	24.1	24.4
	E**	19.1	19.7	20.3	20.6	21.6	22.2	23.2	23.8	24.4	25.1	25.7	26.7	27.3	27.9	28.5	29.2

\*Izņemot apava iekšzoli var palielināt apava iekšējo apjomu par 0.6-1.1cm (atkarībā no apava izmēra).

\*\*Mēru ņemšanas laikā nedrīkst nospriegot mērlenti, lai apavi nebūtu pārlietu cieši.

Visi izmēri norādīti centimetros